

Important: Read all instructions prior to installation.

# 1984-2001 Jeep Cherokee XJ A-Pillar LED Light Brackets

## Parts Included

- 1 - Driver Bracket
- 1 - Passenger Bracket
- 2 - Gaskets
- 6 - 3/16" Rivets

## Tools & Supplies Required

- 3/16" Drill Bit
- Pop Rivet Gun
- Tape Measure
- Masking Tape
- Pencil



## Important

Please read instructions before beginning installation. Check the kit hardware against the kit contents. Be sure you have all the needed parts and know where they go. These brackets are designed to fit 3" square auxiliary lights.

## Application

Only fits 1984-2001 Jeep Cherokee XJ models.

## Installation Instructions

1. Remove door gasket from lower A-pillar.
2. Install the gaskets on the back side of the light brackets. Apply masking tape to A-pillar, and measure to bottom of brackets to ensure equal spacing. Mark the position of the holes in the light bracket.
3. Drill the 3 marked holes on the driver side through the sheet metal with a 3/16" drill bit. Use the supplied 3/16" rivets to secure the light brackets. Repeat steps on the passenger side. **\*Note\* May want to place a piece of tape on the drill bit 1/2" from the end for a depth gauge. Drilling too far will damage the outside painted surface of the A-pillar.**
4. Install the LED lights onto the brackets.
5. Refer to the wiring harness instructions for electrical connections.

## Dimensions

NOTE: THE DIMENSIONS FOR THIS PRODUCT ARE FOR REFERENCE ONLY. SOME BRACKETS ARE ABLE TO SHIFT TO DESIRED POSITION WHEN INSTALLED. USE BRACKETS WITH FIXTURE TO MARK HOLES BEFORE DRILLING.

