

Important: Read all instructions prior to installation.

2010-2014 Dodge 2500/3500 21" Camo LED Light Bar Mount Bracket

Parts Included

- 2 - Light Bar Mounting Brackets
- 8 - M12 x 45mm Bolts
- 8 - M12 Flat Washers

Tools & Supplies Required

- 18mm Socket
- 19mm Socket

Important

Please read instructions before beginning installation. Check the kit hardware against the kit contents. Be sure you have all the needed parts and know where they go. These brackets are designed to fit our 21" Camo single-row LED light bar.

Application

Only fits **Dodge 2500/3500 2010-2014** models.

Installation Instructions

1. Using an 18mm socket, remove the 4 factory bolts holding each tow hook.
2. Place the bracket behind each tow hook (with the light tab toward the inside), and install the tow hook back onto the truck using the supplied M12 x 45mm bolts and washers. Hand tighten.
3. Install your 21" light bar between the brackets and tighten with the supplied bolt that came with the light.
4. Tighten tow-hook bolts with a 19mm socket.
5. Refer to the wiring harness instructions for electrical connections.

Dimensions

NOTE: THE DIMENSIONS FOR THIS PRODUCT ARE FOR REFERENCE ONLY. SOME BRACKETS ARE ABLE TO SHIFT TO DESIRED POSITION WHEN INSTALLED. USE BRACKETS WITH FIXTURE TO MARK HOLES BEFORE DRILLING.

