

Important: Read all instructions prior to installation.

2009-2014 Ford F150 30" Single-Row LED Bar Bracket

Parts Included

2 - Light Bar Mounting Brackets

Tools & Supplies Required

• T-30 Torx bit

Important

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown. Be sure you have all needed parts and know where they go. These brackets are designed to fit a 30" single-row LED light bar.

Application

Only fits **Ford F150 2009-2014** models.

Installation Instructions

1. Pop hood. Using a T30 Torx screwdriver, remove hood stop mount bolt.
2. Next, place light bracket on hood stop mount, and snug the bolt. Repeat process for other side of vehicle (**Do Not Tighten**).
3. Insert your light bar between brackets and secure with bolts that came with the light.
4. Tighten light brackets at hood stop on both sides with T30 Torx screwdriver. **Do not overtighten**.
5. Refer to the wiring harness instructions for electrical connections.

Dimensions

NOTE: THE DIMENSIONS FOR THIS PRODUCT ARE FOR REFERENCE ONLY. SOME BRACKETS ARE ABLE TO SHIFT TO DESIRED POSITION WHEN INSTALLED. USE BRACKETS WITH FIXTURE TO MARK HOLES BEFORE DRILLING.

