

Important: Read all instructions prior to installation.

Pairing Procedure for all MiBoxer Remotes

1. Make sure all connections are secure. Power supply and LEDs should all be hooked up and powered on.
2. Completely disconnect power through any of these methods:
 - Unplug connector going to the MiBoxer controller.
 - If using a power cord, unplug power supply from the wall.
 - If hardwired to a switch, simply turn off the switch.
3. With supply power off, touch any button on the remote and verify that the DOT in the middle of the color wheel lights up.
4. Start pressing the (I) button repeatedly. Zones are shown in example graphic to the right. Each zone contains it's own (I) button and a (O) button.
5. Continue pressing (I) button as you restore power to the controller. Do not stop pressing (I) button until you see the LEDs starting to flash. Stop pressing (I) button repeatedly.
6. Once LEDs stop flashing, zone control has been successfully connected.

