

Important: Read all instructions prior to installation.

LED Bulkhead Light



Safety and Notes

- Product should be installed and serviced in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- Avoid looking directly into lamp when illuminated.
- Ensure all mounts are securely attached and will support the weight of the fixture. Failure to properly support fixture may result in damage or injury, for which the manufacturer does not assume responsibility.

Specifications

Environmental Specifications	
Operating Temperature	-13°–104° F (-25°–40° C)
IP Rating	IP54

Check product label for specific electrical specifications related to installation. Improper installation will void warranty.

Installation

1. Turn off breaker/switch to cut power.
2. Attach mounting bracket to junction box.
3. Mount light housing base to mounting bracket.
4. Connect wiring.
5. Attach outer light housing.

