# superbrightleds.com

Important: Read all instructions prior to installation.

# PAR36 RGB Light with Remote

### **Safety and Notes**

- To reduce risk of electric shock, ensure power is disconnected before performing any installation procedures.
- Avoid looking directly into lamp when illuminated.
- Product should be installed in accordance with local building and electrical codes.

#### **Included Parts**

- 1 PAR36 Bulb
- 1 IR Remote Controller

### **Specifications**

PAR36-RGB9W-160-IR	
Operating Voltage	12 VDC/VAC
Rated Power Consumption	9 W
Beam Angle	160°
Dimming	with remote
Operating Temperature	-49–131°F (-45–55° C)
IP Rating	IP68
Remote Type	IR
Remote Battery Type	2032

# User Manual

# PAR36-RGB9W-160-IR



## **Remote Diagram**



## **Wireless Remote Functions**

#### ON / OFF

Press 'ON' key to turn on unit or press 'OFF' key to turn off. Retains last setting between power off and power on.

#### 3-Stage Brightness Adjustment

Increases or decreases the brightness of the currently active color. This adjustment doesn't affect patterns.

#### **Color Selection**

Activates the static color indicated by the button color.

#### Patterns

Selecting one of the four patterns will activate that pattern. Patterns operate in RGB mode.

