Important: Read all instructions prior to installation.

LED Post-Top Area Light

Included Parts

- 1 area light
- 1 shorting cap or photocell (depending on model)
- 4 position locking screws
- 6 post locking screws

Safety and Notes


- · Product should be installed by a certified electrician in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- Avoid looking directly into the lamp when illuminated.
- Ensure all mounts are securely attached and will support the weight of the fixture. Failure to properly support the fixture may result in damage or injury, for which the manufacturer does not assume responsibility.

Installation Instructions

- 1. Rotate light to correct angle and lock in place using provided screws.
- 2. Install shorting cap/photocell.
- 3. Remove supply power from intended circuit.

- 4. Connect wiring, as shown in diagram below. Note: Lead wire is 48" long.
- 5. With retaining screws backed out, place light on top of post. Tighten in place.
- 6. Reapply supply power.

7777777777777777777777777



Specifications


PTLP-	xK75W-HT2BR	xK100W-HT2BR	xK150W-HT2BR
Power Consumption	75 W	100 W	150 W
Operating Voltage Range	100–277 VAC		
Beam Angle	90°		
Dimming	with photocell [on at 10 lx (dusk), off at 60 lx (dawn)]		
Ambient Operating Temperature	-4–113° F (-20°–45° C)		
IP Rating	IP65		
Weight	15 lb (6.8 kg)		
Mounting Pole Diameter	2–3 in. (52–76 mm)		
Mounting Pole Height	6.5–26.25 ft (2–8 m)		

Tighten screws to

(6mm hex)

secure to lamp post

Wiring Diagram



User Manual

PTLP Series







Tighten screws 90 degree on both ends rotation