

User Manual

TC-TSL-13W-50K-5

Important: Read all instructions prior to installation.

LED Temporary Job Site Lights

Safety and Notes

- · Warning: Switch off the supply power before/during installation.
- This product should be installed in accordance with all applicable national, state, and local building and electrical codes.
- · Avoid looking directly into the lamp when illuminated.
- Ensure mounts are securely attached and will support the weight of the lights. Failure
 to properly support lights may result in damage or injury, for which the manufacturer
 does not assume responsibility. No additional weight should be applied to or hung
 from the lights/cables.
- Supply power can be linked (see spec table for max run). Do not use with dimmers or extension cords or modify wiring/connection.
- Do not install in a location that is in proximity to a radiant heater.
- Lights must be connected to GFCI-protected receptacle only. Keep plugs and receptacles dry.
- If cleaning is necessary, use a damp cloth to wipe down case. Do not spray lights with pressurized water or expose to steam.
- Do not use within 16 ft (5m) of large areas of standing water such as pools, spas, or fountains.



Specifications

Model	TC-TSL-13W-50K-5
Operating Temperature	-4°-113° F(-20°-45° C)
IP Rating	IP65
Max Run	6 strands

Check product label for specific electrical specifications related to installation.

Improper installation will void warranty.

Hanging Instructions

Hang using provided carabiners. Do not pull wiring/power cable or use them to support weight other that the lights themselves.

Linking Instructions

Lights can be linked in a run up to the maximum run of 6 light strands. To link lights, simply remove plug end from one light string and plug it into another. When linking lights, make sure connector is fully engaged and tightened so cord can't accidentally become unplugged or allow water intrusion. Do not attempt to connect cables while power is on or while conditions are wet.









