

Important: Read all instructions prior to installation.

Mechanical Timer

Product




! WARNING Risk of Fire or Electrical Shock

- Risk of injury or death. Always plug three-prong plug into a properly grounded outlet. Never attempt to defeat this safety feature.
- Do not use timer to control devices that could have dangerous consequences due to inaccurate timing, such as sun lamps, sauna, heaters, crock pots, etc.
- Unplug timer before replacing batteries

NOTICE

- Follow local electrical codes during use.
- Dispose of used batteries promptly per local regulations.

Diagram 1



Setting the Programs

- 1. To set present time:** Turn the programming dial in the direction of the arrow until the triangular mark corresponds with the present time.
- 2. To program:** Ensure the arrow is on the present time. Push in the gray trippers situated around the dial to set equipment "ON" time. Each tripper represents 30 minutes.
- 3. Example:** If you would like to set the time of activation from 7:00PM to 11:30PM, then push down the trippers situated between 7:00PM and 11:30 PM, including the segments corresponding with 7:00PM and 11:30PM (see diagram 1).
- 4. To activate equipment:** having selected your program, plug in your equipment to the timer and then plug the timer into a 125 Volt circuit. The timer will activate and deactivate the equipment as the dial rotates through the pushed down segments.
5. The selected program will remain the same each day unless modified by customer.

WARNING: DO NOT OVERLOAD